



RAINIERTENTS TechTips

INSTALLING HOOKS AND CORDS TO SIDEWALL EXTENSIONS

Preparation

Making sidewall extension properly is a function of keeping the over-flap tied down. Installing shock cords and sidewall tent hooks should do the job.

Installation of Sidewall Tent Hooks and Shock Cords

1. Install 4" x 4" doubler (reinforcement) on existing wall. Punch 1/4" hole for Stayput Hooks
2. Assemble Stayput hooks by tapping with hammer until button is set into fabric.
3. Each sidewall should have four (4) Stayput sidewall hooks.
4. Position each hook so the shock cord fits snugly when snapped into place.
NOTE: Do not place too low on wall, making the shock cord stretch when it is connected.
5. Install Shock Cords if necessary



1.800.621.2495

www.RainierTents.com
tentinfo@rainier.com